



CHEMPROX SOFTWARE UPDATE NOTIFICATION FOR **ChemProX Software Version 1.7.1**

Dear Environics Partner,

As part of the ChemProX product support we release software updates to make sure, that users have best and up to date chemical detector at their disposal. These updates can contain detection mode updates, functionality updates and more.

We have now released **software version 1.7.1**, that includes the following updates for ChemProX:

- Dynamic radio data;
 - Chemical and radiation trend view in CCT UI
 - Ability to change detection mode remotely in CCT UI
- New detection mode selection view
- Improved usability
- Improved stability

Please refer to ChemProX User & Maintenance Manual for further information about the updated features.

To get this latest software update and to install it in ChemProX follow these simple steps:

1. go to address update.environics.fi with your web browser
2. Enter ChemProX serial number and security code. For the information where to find serial number and security code press ?-button. By pressing the +-button you can enter information for multiple devices
3. Press check- button. Update station will tell you if you have updates available for your devices. You will also see release notes that tell you what is new in this update.
4. Download the update file to your computer
5. Put the update file into USB-stick in root folder
6. Connect USB-stick into ChemProX with USB Connector Cable (Standard accessory)
7. USB-menu will open automatically. Select "Install Update"
8. Select the update file and let the update process run through
9. You have now updated your ChemProX!

If you have any questions regarding the update or update process, please don't hesitate to ask.

Mika Saarinen

PRODUCT MANAGER

HANDHELD CHEMICAL DETECTORS

+358 40 350 2620

mika.saarinen@environics.fi



WE SENSE & DETECT
Environics **FOR A SAFER WORLD**